

Remote Sensing of Atmospheric Aerosols with the Spectropolarimeter SPEX

Jos de Boer, Gerard van Harten, Frans Snik, Otto Hasekamp, Hester Volten, Arnoud Apituley, Christoph Keller, Jeroen Rietjens, Martijn Smit, Daphne Stam, and Piet Stammes

Sterrewacht Leiden [LU]

COST, Warsaw, May 7, 2012

What are Aerosols

Fine Dust

Particulate Matter (PM)

Examples of Aerosols:

- soot
- (black/white) smoke
- dust
- waterdroplets
- airborne desert-sand
- pollen or spores
- sea salt
- ...

What are Aerosols

Fine Dust

Particulate Matter (PM)

Examples of Aerosols:


- soot
- (black/white) smoke
- dust

Why Aerosols are Important

Aerosols have impact on:

- Health
- Climate
- Economy



Why Aerosols are Important



Aerosols have impact on:

- Health
- Climate
- Economy


Why Aerosols are Important



Aerosols have impact on:

- Health
- Climate
- Economy

Why Aerosols are Important




- Health
- Climate
- Economy



Radiative forcing of climate between 1750 and 2005

Radiative Forcing Terms



What we want to know:

- Column density
- Spatial distribution
- Size Distribution
- Complex refractive index
- Shape

What we want to know:

- Column density
- Spatial distribution
- Size Distribution
- Complex refractive index
- Shape




Figure: PM 2.5 map. Van Donkelaar e.a. (2010)

What we want to know:

- Column density
- Spatial distribution
- Size Distribution
- Complex refractive index
- Shape





Figure: PM 2.5 map. Van Donkelaar e.a. (2010)

Why Spectropolarimetry



Laan et al (2007)





SPEX_RIVM



Blue-sky SPEX Measurements



Blue Sky SPEX Measurements




Figure: Scattering angle = $8.4^\circ \pm 1.4^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $18.6^\circ \pm 0.7^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $28.8^\circ \pm 0.5^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $39.1^\circ \pm 0.4^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $49.4^\circ \pm 0.2^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $92.8^\circ \pm 0.1^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $103.0^\circ \pm 0.1^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $113.1^\circ \pm 0.2^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $123.4^\circ \pm 0.2^\circ$

Blue Sky SPEX Measurements




Figure: Scattering angle = $133.5^\circ \pm 0.3^\circ$

Blue Sky Polarization




Figure: Degree of Linear Polarization (DoLP) for different scattering angles

Look-up Table Retrieval Code




Figure: Block diagram of Aerosol Parameter Retrieval

Look-up Table Retrieval Code






Figure: Look-up table retrieval code as described by Hasekamp et al. (2011)

Surface Albedo and Aerosol Optical Thickness



Retrieval of Aerosol Properties




Figure: Degree of Linear Polarization (DoLP) for different scattering angles

Retrieval of Aerosol Properties





Figure: Degree of Linear Polarization fitted against model

What's next



What's next



SPEX Concept


SPEX Concept



$\lambda/4$
retarder
 $(+Q)$



multi-order
retarder
 $(+U)$




polarizing
beamsplitter
 $(\pm Q)$

spectro-
graph

SPEX Concept

$Q \rightarrow Q$
 $U \rightarrow V$
 $V \rightarrow U$




$\lambda/4$
retarder
(+Q)

$Q \rightarrow Q, V$
 $V \rightarrow Q, V$
 $U \rightarrow U$





multi-order
retarder
(+U)

$Q \rightarrow 0, \pm Q$
 $U \rightarrow \pm 1/2Q$
 $V \rightarrow \pm 1/2Q$



polarizing
beamsplitter
($\pm Q$)

SPEX_RIVM Design






Figure: Spectral modulation of spectrograph channel 1




Figure: Spectral modulation of spectrograph channel 1




Figure: Spectral modulation of spectrograph channel 1 and 2




Figure: Spectral modulation of spectrograph channel 1 and 2